

NORTH SAILS

J/109 Quick Reference Tuning Guide

Basic Set-Up			
Mast Step	460mm-Mast step is measured from forward face of mast to aft edge of bulkhead		
Headstay	2260mm-Arc measurement*		
Pre Bend	20mm-With no mainsail up		

*Arc Measurement-pull genoa halyard to the top of the black band at the gooseneck. Swing the halyard out to the headstay and make a mark.Measure from mark down to the deck at the headstay intersection.

Rig Tensions-Using RT-10			
True Wind	Upper Shroud V1	Lower Shroud D1	Intermediate Shroud D2
0-10	Minus 4 Turns	Minus 2.5 Turns	Minus 2.5 Turns
10-15 BASE	55	30	15
15-20	Plus 3 Turns	Plus 2 Turns	Plus 2 Turns